



- A CONTROL AIR SUPPLY UNIT
- B FUEL SUPPLY
- D SERVO OIL SUPPLY
- E VALVE UNIT FOR START
- H INSTRUMENT PANEL
- I PRESSURE SWITCHES AND PRESSURE TRANSMITTERS
- K LOCAL CONTROL PANEL
- L CONTROL OIL PUMP UNIT
- M SPEED SETTING SYSTEM
- N CRANK ANGLE SENSOR UNIT
- O SPEED PICK-UPS
- P, Q, R, S, T, U, V, W, X, Y, Z (Various components and sensors)

SURFACE PROTECTION SEE GROUP 0344  
 GENERAL TOLERANCES ACCORDING TO ISO 2768-M

7-29-405	11.12.03				
Number	Date	Number	Date	Number	Date
Scale 1:1					
ENGINE CONTROL DIAGRAM					
CAD					
WARTSILA					